

Items Supplied >

1 - FRONT MUFFLER ASSEMBLY

1 - REAR MUFFER ASSEMBLY

2 - CLAMP, 27-61MSC

Application >	www.cobrausa.com
FAT BOB	08-13
WIDE GLIDE	10-13


Instruction Manual >

6006B

Page 1 of 1

Read all instructions carefully and completely before installing your new slip-on mufflers

- Remove the stock mufflers carefully and save the mounting bolts.
- 2. Slide the supplied 27-61MSC clamps over the slip-on mufflers and position them as shown in Figure 1.
- NOTE: THE MUFFLER WITH THE COBRA LOGO WILL ALWAYS BE THE REAR CYLINDER. Slide the mufflers onto the headpipes until the mounting holes align.
- Fasten the mufflers using the stock mounting bolts in the same manner as stock but do not tighten. Verify that the gap, where the mufflers meet the stock heatshields, is similar to the gap the stock mufflers allotted.
- Check all clearances and alignments then tighten the clamps. (NOTE: If the muffler clamps are slid past the slots on the slip collar the clamps will not tighten the mufflers properly). Tighten the mounting bolts to factory specifications.
- 6. NOTE: The exhaust tips may be loosened and oriented to various positions for different visual effects.



PICTURED MOUNTING BRACKETS MAY VARY FROM ACTUAL APPLICATION

REPLACEMENT E-GLASS PACKING AND OPTIONAL 1¾" QUIET CORES MAY BE PURCHASED THROUGH YOUR DEALER OR ONLINE AT WWW.COBRAUSA.COM

IMPORTANT: To achieve optimum performance from your new mufflers it is suggested that you install a Cobra Fi2000® Digital Fuel Processor. Visit www.fi2000r.com

To clean your black exhaust system use a liquid based soap detergent, such as dishwashing soap applied with a soft cloth and rinse with clean water. Note: Avoid abrasive cleaning methods such as granular or dry cleansers, simple green, scotch-brite or steel wool pads. Abrasives may breach the coating and shorten life.

California does not allow the use of aftermarket exhaust systems that remove original equipment catalysts, (except for racing use only) unless the Air Resources Board has issued an Executive Order for that system.

Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.