

BIG TWIN HIGH PERFORMANCE A/C ASSEMBLY



090525D 11/14/2011

REQUIRES:

1/4" 12 Point Wrench
3/8" 12 Point Wrench
3/16" Allen Wrench

IMPORTANT: A/C assembly will not run properly without remapping the E.F.I. system

NOTE: Use BLUE LOCTITE on all hardware

INSTALLATION

1. Completely remove stock air cleaner assembly.
2. Secure the loose pigtail with a zip-tie to the throttle position switch wiring harness.
3. Installed the a/c back plate & vent plates with the breather bolts.
Do not fully tighten the breather bolts
4. Install the (3) 1/4-20 Allen screws using blue Loctite to the throttle body with the stock a/c gasket.
5. Tighten the breather bolts
6. Install the outer cover, K&N filter, and stand-off with the 1/4-20 12 point bolt using blue Loctite.

