

# **INSTALLATION**

# **ISO BRAKE PEDAL PAD**

8029

#### **CUSTOMER SERVICE**

877.370.3604 (toll free)

## INSTALLATION QUESTIONS

techsupport@kuryakyn.com or call 715.247.2983

#### LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- · Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
  - •The product must be properly installed, maintained and operated under normal conditions.
  - •Kürvakvn makes no warranty, expressed or implied, with respect to any gold plated
- •Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Kürvakvn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- •Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kürvakvn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year This includes, but is not limited to: control modules, wiring, chrome & other components.
- •Küryakyn makes no warranty of any kind in regard to other manufacturer1s products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

#### **ABOUT OUR CATALOG**

For purchasing Küryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved

# **PARTS INCLUDED**

- Chrome Base 1
- Large Rubber Insert 1
- 2 Small Rubber Insert
- 1/4"-20 x 3/4" Flat Socket Cap Screw— Stainless 1
- 1/4" I.D. Split Lock Washer Chrome 1
- 1 Hi Crown, 1/4"-20 Acorn Nut — Chrome
- 1 **Installation Instructions**

Please read and understand entire instructions before starting installation.

## THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

### **TOOLS SUGGESTED**

Set of Hex Wrenches, Set of Combination Wrenches

#### STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the

installation. Park the motorcycle on a hard, level surface and turn off the

ignition.

STEP 2 Remove the stock brake pedal pad.

STEP 3 Lift the center rubber pad from its "pocket".

STEP 4 Set the new Brake Pedal Pad on to the pedal. Secure it with the  $1/4''-20 \times 3/4''$ 

flat socket cap screw, lock washer, and acorn nut. Tighten securely.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

STEP 5 Carefully clean the bare center pocket with acetone, alcohol, etc., and let dry.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

STEP 6 Remove the adhesive backing from the rubber pad, and affix the pad into the Pocket.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than

8029-21HD-0911



