



MOUNTING SUGGESTIONS:

**Triumph Bonneville/T100/
Scrambler/Thruxton '01-17**
One-piece Seat

Hardware:	Stock 6mm screws
Tools needed:	5mm Allen wrench

Note: Will not fit T120 or Street models.

Removal of stock seat:

1. Remove the two stock 6mm Allen bolts from under the rear of the seat and set them aside. These will be used to attach your new Mustang seat.



2. Lift the rear of the seat up and back to disengage the front bracket and remove the seat.

Installation of Mustang seat:

1. Insert the nose bracket into the frame receptacle behind the tank.
2. Secure the rear of the seat with the two stock 5mm bolts.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 76827, 76828

You are cordially invited to
— Tour the Mustang Factory —

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.