



MOUNTING SUGGESTIONS:

Harley-Davidson® FLHT/FLTR 1997-2007 One-piece Seat

Hardware: Stock 1/4"-20 x 1/2" rear fender screw

Tools needed: Phillips screwdriver

Note: CVO models 1997-2005 have a lower dash than other FLHT and FLTR models. Use seats designed for FLHR and FLHX on these Screamin' Eagle models.

Removal of Stock Seat:

One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.
2. Remove hand strap that is secured to the motorcycle on each side of the seat where the front saddlebag mount is located.
3. Slide the seat up and back to disengage the front bracket and remove the seat.



Installation of Mustang Seat:

1. Remove any seat supports from the frame rails and be sure wiring is routed along the inside of the frame rails.
2. If the seat is heated, connect the cable to the accessory port. Be sure port is free of dirt and debris. If the accessory port is already in use, use Harley® part 70264-94A or 70270-04 to add additional ports. Check to be sure there are no folds or kinks in the wire before installing seat.
3. Engage the nose bracket into the frame.
4. A firm downward punch or chop to the nose of the seat will push the seat closer to the chrome dash. If there is a gap at the dash, the dash can be adjusted by loosening the ½" hex nut and Phillips screw on the dash, sliding the dash back and retightening. On 2004 and newer models, the seat's nose bracket can be bent away from seat about ¼" for best fit.
5. The seat is spring-loaded, so the rear mounting bracket will be approximately 1" to 1-1/2" above the fender mount. Gently push seat down and secure to fender with stock screw.
6. Mustang suggests that a rack-mounted backrest be set to the rearmost position. Fully loosen the four nuts under the outer rack channels and tap the backrest rearward to the end of the slots, and retighten the nuts.

Using a Backrest:

1. Using a backrest with seats with a split in the baseplate between the rider and passenger seats requires first mounting a Harley® or Mustang frame-mounted backrest kit. The post on the Mustang kit is bent to account for the angle. It may be necessary to add washers as spacers to the front mount to refine the angle.
2. Seats without a split in the baseplate but with a split in the cover use a straight-post Mustang backrest. A bent-post backrest from a frame-mounted backrest kit will not work with these seats.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75448, 75449, 75454, 75455, 75537, 75570, 76382, 76587, 76589, 76652, 76653, 76970, 76971, 76983, 79456

You are cordially invited to
— Tour the Mustang Factory —

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.