



# INSTALLATION



## SPLINED ADAPTER MOUNTS 8808

**FRONT APPLICATIONS: HONDA: ALL '01-UP GL1800; SUZUKI: '01-UP BOULEVARD M50/VOLUSIA 800 AND '06-UP M109R.**  
**NOTE: NOT FOR USE WITH PEG MOUNTED FLOORBOARDS ON GL1800 OR OTHER MOTORCYCLES WITHOUT ADJUSTABLE SHIFTER POSITION.**

### PARTS INCLUDED

- 2 Splined Adapter Mount
- 4 "D" Spring Washer
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

### THANK YOU FOR CHOOSING KÜRYAKYN!

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

### TOOLS SUGGESTED

Needle nose pliers

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

### PROCEDURE

**STEP 1** Park the motorcycle on a hard, level surface; turn off the ignition.

**STEP 2** Remove the hardware securing the footpeg to the footpeg mount. Set the hardware aside for now, it will be re-used.

**ATTENTION!** Note the location and orientation of return springs (where applicable) before disassembly.

**STEP 3** Remove the existing footpeg and spring where applicable; set the footpeg and spring aside for now.

**-cont.-**

### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

· Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).

· The product must be properly installed, maintained and operated under normal conditions.

· Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

· Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.

· Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.

· Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.

· Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



**NOTE** The four "D" Spring Washers have been included for use when the existing footpeg is missing the stock return spring. Install the "D" Spring Washers on either side of the Splined Adapter Mount with the flat of the "D" facing inboard.

**STEP 4** Install the Splined Adapter Mount as you would the existing footpeg. Ensure that the squared off end of the Adapter Mount is on the bottom when installed. Ensure that the curved end of the spring locates over the Splined Adapter Mount as shown in PIC.1.

**STEP 5** Install the hardware in the reverse order it was removed in STEP 2.

**NOTE** Push down on the spring to install the pivot pin.

**ATTENTION!** It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

**STEP 6** Repeat STEP 2 through STEP 5 for the other side.

**STEP 8** Use the instructions included with the new footboards/footpegs to complete the installation.

**WARNING!** IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

**CAUTION!** Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

**PIC.1**



*Ride On!*