

MOUNTING SUGGESTIONS:

Harley-Davidson[®] Dyna 1991-1995

Solo and Passenger Seat

Hardware: Stock rear screw

1/4"-20 x 1/2" screws x 2 (solo)

Long and short rear bracket (passenger seat)

10/32 x 5/8" screws x 2 (passenger seat)

Tools needed: Phillips screwdriver

Removal of Stock Seat:

- 1. Remove the rear fender screw and set aside. This screw will be used to mount your Mustang seat.
- 2. Remove handstrap if present.



3. Lift the stock seat up and back to remove from motorcycle.

Note: Mustang solos and passenger seats will not work with stock seats.

Installation of Mustang Seat:

1. If installing the passenger seat with the solo, join the passenger seat to the solo with the supplied $\frac{1}{4}$ "-20 x $\frac{1}{2}$ " screws and install as a one-piece unit.



2. If installing the passenger seat with the solo, attach the rear bracket to the passenger seat with the supplied 10-32 \times 5/8" screws. Use the longer bracket for 1993-1995 FXDWG Wide Glides, and the shorter bracket for other models.



3. Engage the nose bracket of the solo seat with the welded frame tab.

- 4. Align the rear bracket with the fender mount. The bracket may be as much as 1" over the fender mount.
- 5. Push the rear bracket down and secure it to the fender with the stock screw.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75752, 75753

You are cordially invited to Tour the Mustang Factory

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.