



INSTALLATION

LIGHTNING VALVE COVERS

3901

PARTS INCLUDED

- 1 Left Upper Cover
- 1 Left Lower Cover
- 1 Right Upper Cover
- 1 Right Lower Cover
- 4 Alcohol Pads
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

NOTE: Our Lightning Valve Covers are stunning chrome die-cast covers designed to shroud the existing valve covers. The design of the lower Lightning Covers allows them to be removed as a unit with the stock covers for easy access to the spark plugs. Removal of the stock upper valve covers requires the upper Lightning Covers be removed to allow access to the fasteners. When prying the Lightning covers free, care must be taken to avoid damaging both the lightning covers and the stock covers beneath. Contact us at toll free (866) 277- 9598 to purchase replacement adhesive pads, P/N 3902, should the covers need to be removed and replaced.

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



kuryakyn.com

-cont.-

3901-21GL-0911

STEP 2 Place the bike on its center stand.

STEP 3 Identify each Lightning Valve Cover and note its proper location for installation on the motorcycle. PIC 1

STEP 4 Select one of the four Lightning Valve Covers. Without removing the backing from the adhesive pads, test fit the cover. If necessary, temporarily remove any accessories (highway pegs, etc.) that inhibit installation.

STEP 5 Remove any grease or debris from the valve covers with soapy water and a clean rag; allow the area to dry completely. Clean the valve covers with the included alcohol cleaning pads to remove any residue and allow the area to dry completely.

ATTENTION! Thoroughly clean the area of grease, oil, dirt, or other debris to ensure proper adhesion. Küryakyn WILL NOT warranty any parts lost due to improper installation.

ATTENTION! The adhesive may not correctly bond if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 6 Rub each pad firmly with your fingernail BEFORE removing the backing to activate the adhesive contained in the foam core of the pad. Once you have activated all pads, remove the backing from each and maneuver the cover into position. Hold it firmly in place for one full minute to ensure a good initial bond. Full bonding will occur in 24 hours.

STEP 7 Repeat STEP 5 and STEP 6 for the remaining three Lightning Valve Covers.

STEP 8 Replace any accessories that may have been removed in STEP 4.

ATTENTION! It is the installer’s responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

STEP 9 Start the bike and allow it to run until it reaches normal operating temperature. After five minutes at normal operating temperature, turn the bike off and allow it to sit over-night (10-12 hours).

